



INSTRUCTIONS FOR
WORKSHOP PUMP
 MODEL NO: **BC110.V2**

Thank you for purchasing a Sealey product. Manufactured to a high standard, this product will, if used according to these instructions, and properly maintained, give you years of trouble free performance.

IMPORTANT: PLEASE READ THESE INSTRUCTIONS CAREFULLY. NOTE THE SAFE OPERATIONAL REQUIREMENTS, WARNINGS & CAUTIONS. USE THE PRODUCT CORRECTLY AND WITH CARE FOR THE PURPOSE FOR WHICH IT IS INTENDED. FAILURE TO DO SO MAY CAUSE DAMAGE AND/OR PERSONAL INJURY AND WILL INVALIDATE THE WARRANTY. KEEP THESE INSTRUCTIONS SAFE FOR FUTURE USE.



Refer to instructions

1. SAFETY

- WARNING!**
- ✓ Read operating instructions before use.
- ✓ Check capacity and maximum inflation pressure of inflatable before commencing inflation.
- ✓ Monitor the pressure gauge while in operation. The gauge should be used as an indication of pressure only. We recommend the use of a dial pressure gauge for definitive reading.
- WARNING! DO NOT** inflate any item beyond its maximum capacity.
- ✗ **DO NOT** carry by the hose, or yank the hose from an inflation valve.
- ✗ **DO NOT** use the pump for a task it was not designed to perform.
- ✗ **DO NOT** operate the pump when you are tired, under the influence of alcohol, drugs or intoxicating medication.
- ✗ **DO NOT** operate the pump if any parts are missing as this may cause failure or possible personal injury.
- ✓ Keep children and non essential persons away from the inflation area.
- ✓ Keep the pump clean and in good condition.
- ✓ Replace or repair damaged parts.

2. INTRODUCTION

Durable construction with chrome plated steel upright tube. Dial type high pressure gauge with rotating bezel. Gauge calibrated in psi and bar with ranges from 0-160psi and 0-8 bar. Fitted with twin head for both Presta and Schrader valves and a 360° rotatable hose. Features a wide base for added stability with foldable foot stand. Supplied with accessories for inflating items such as small inflatable boats, air beds and balls stored in a compartment located in the handle.


3. SPECIFICATION

Model No..... BC110.V2

4. OPERATION



Maintenance





- 4.1. Remove all packaging and fold out feet fig.2.
- 4.2. Select correct connector fig.4 /fig.5 for required valve and attach to pump hose as required / push or attach to valve.
- 4.3. Place foot on pump foot fig.6, grasp handles. raise and lower handles to pump air into item to be inflated.

5. MAINTENANCE

- 5.1. Keep pump clean, by wiping with damp rag.
- 5.2. Store in a dry, child proof area.



Environmental Protection

Recycle unwanted materials instead of disposing of them as waste. All tools, accessories and packaging should be sorted, taken to a recycling centre and disposed of in a manner which is compatible with the environment. When the product becomes completely unserviceable and requires disposal, drain off any fluids (if applicable) into approved containers and dispose of the product and the fluids according to local regulations.

NOTE: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice.

IMPORTANT: No liability is accepted for incorrect use of this product.

WARRANTY: Guarantee is 12 months from purchase date, proof of which will be required for any claim.



Sole UK Distributor, Sealey Group.
Kempson Way, Suffolk Business Park,
Bury St. Edmunds, Suffolk.
IP32 7AR



01284 757500



01284 703534



www.sealey.co.uk



sales@sealey.co.uk