

12 SMD LED + 6 SMD LED ROTATING HAZARD WARNING EMERGENCY LIGHT

MODEL NO: LED040

Thank you for purchasing a Sealey product. Manufactured to a high standard, this product will, if used according to these instructions, and properly maintained, give you years of trouble free performance.

IMPORTANT: PLEASE READ THESE INSTRUCTIONS CAREFULLY. NOTE THE SAFE OPERATIONAL REQUIREMENTS, WARNINGS & CAUTIONS. USE THE PRODUCT CORRECTLY AND WITH CARE FOR THE PURPOSE FOR WHICH IT IS INTENDED. FAILURE TO DO SO MAY CAUSE DAMAGE AND/OR PERSONAL INJURY AND WILL INVALIDATE THE WARRANTY. KEEP THESE INSTRUCTIONS SAFE FOR FUTURE USE.



Refer to instructions

1. SAFETY

- ✓ Familiarise yourself with this product's application and limitations, as well as any specific potential hazards peculiar to the warning light
- **DO NOT** use the warning light for any purpose other than for which it is designed.
- **DO NOT** allow children to operate the warning light.
- PO NOT operate the warning light if any parts are missing or damaged as this may cause failure or possible personal injury.
- ✓ When not in use switch the warning light off and where appropriate remove batteries.

2. INTRODUCTION

Rotating warning light is ideal to keep in the car for a variety of roadside emergency applications and hazard awareness. Durable, waterproof (IPX5) and extremely heavy-duty design. Features nine different warning functions with 12 ultra-bright amber coloured SMD LEDs and three white SMDs for use as a torch producing 150 lumens. Visible 360° at 500m distance. Includes three magnets for adhering to any ferrous material and hanging hook for hands-free operation. Powered by 3 x AAA batteries (not included).

3. SPECIFICATION

Model No:	LED040
Battery:	3 x AAA (not included)
Dimensions:	130 x 120 x 45mm
LED Qtv:12 x Amber SMI	D LED + 6 x White SMD LED

4. OPERATION

- **4.1.** To turn on the light press the power button on the top of the unit (fig.1).
- **4.2.** Keep pressing the power button to change the functions.
- 4 2 1 Functions

White 6 SMD Light on, Amber Double Flash Quick, Double Flash Slow, Single Flash, Rotate, Alternate Flash,

SOS,

All Amber Light On,


2 x Amber On.

- 4.3. CHANGING THE BATTERY
- 4.3.1. To change the battery unscrew the battery cover (fig.2) on the back and replace the batteries.

5. MAINTENANCE

- 5.1. To clean, wipe with a damp cloth.
 - DO NOT use harsh detergents.







ENVIRONMENT PROTECTION

Recycle unwanted materials instead of disposing of them as waste. All tools, accessories and packaging should be sorted, taken to a recycling centre and disposed of in a manner which is compatible with the environment. When the product becomes completely unserviceable and requires disposal, drain any fluids (if applicable) into approved containers and dispose of the product and fluids according to local regulations.



WEEE REGULATIONS

Dispose of this product at the end of its working life in compliance with the EU Directive on Waste Electrical and Electronic Equipment (WEEE). When the product is no longer required, it must be disposed of in an environmentally protective way. Contact your local solid waste authority for recycling information.



BATTERY REMOVAL SEE 4.4

Under the Waste Batteries and Accumulators Regulations 2009, Jack Sealey Ltd are required to inform potential purchasers of products containing batteries (as defined within these regulations), that they are registered with Valpak's registered compliance scheme. Jack Sealey Ltd Batteries Producer Registration Number (BPRN) is BPRN00705.

Note: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice.

Important: No Liability is accepted for incorrect use of this product.

Warranty: Guarantee is 12 months from purchase date, proof of which is required for any claim.

Sealey Group, Kempson Way, Suffolk Business Park, Bury St Edmunds, Suffolk. IP32 7AR

1 01284 757500 01284 703534 sales@sealey.co.uk www.sealey.co.uk