



Item	Part No.	Description
1	SA19SV2-01	Housing
2	SA19SV2-02	Valve Stem
3	SA19SV2-03	Trigger Assembly
4	SA607V2-42	Spring Pin
5	SA19SV2-05	Valve Seat
6	SA19SV2-06	Throttle Valve
7	SA19SV2-07	Spring, Conical
8	SA19SV2-08	Retainer
9	SA19SV2-09	Muffle Cover
10	SA19SV2-10	Grip
11	SA19SV2-11	Air Inlet
12	SA19SV2-12	Spring
13	SA19SV2-13	Tip, Sleeve
14	SA19SV2-14	Pin
15	DH03.V2-39	O-Ring
16	SA19SV2-16	Air Regulator
17	SA19SV2-17	O-Ring

Item	Part No.	Description
18A	B/625ZZ	Bearing
18B	SA19SV2-18B	End Plate
18C	SA19SV2-18C	Rotor
18D	SA19SV2-18D	Rotor Blade
18E	SA19SV2-18E	Rotor Spacer
18F	SA19SV2-18F	Cylinder
18G	SA19SV2-18G	Set Pin
18H	SA802.23	O-Ring
18I	SA19SV2-18I	Front Plate
18J	SA19SV2-18J	Pin
18K	B/608ZZ	Bearing
18L	SA19SV2-18L	Connecting Rod
19	SA19SV2-19	Retainer
20	SA19SV2-20	Disc Holder
21	SA19SV2-21	Wrench
--	SA19SV2-18	Cylinder Assembly (Not Shown)

NOTE: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice. There may be alternative versions of this product, please contact us should you require this information.

IMPORTANT: No liability is accepted for incorrect use of product. Spare parts must be fitted by a competent person

WARRANTY: Guarantee is 12 months from purchase date, proof of which will be required for any claim.