



INSTRUCTIONS FOR:  
**LANTERNS 4 SMD, 10 SMD LED**  
 MODEL NO'S: **LED181, LED182**

Thank you for purchasing a Sealey product. Manufactured to a high standard, this product will, if used according to these instructions, and properly maintained, give you years of trouble free performance.

**IMPORTANT:** PLEASE READ THESE INSTRUCTIONS CAREFULLY. NOTE THE SAFE OPERATIONAL REQUIREMENTS, WARNINGS & CAUTIONS. USE THE PRODUCT CORRECTLY AND WITH CARE FOR THE PURPOSE FOR WHICH IT IS INTENDED. FAILURE TO DO SO MAY CAUSE DAMAGE AND/OR PERSONAL INJURY AND WILL INVALIDATE THE WARRANTY. KEEP THESE INSTRUCTIONS SAFE FOR FUTURE USE.



Refer to instruction manual



Keep away from rain

## 1. SAFETY

### 1.1. General

- \* **DO NOT** use the lantern if you suspect that the battery or the lantern casing is damaged.
- \* **DO NOT** leave batteries in a discharged state. Before storage remove batteries and dispose of in the correct manor.

### 1.2. Battery Safety

- WARNING!** To reduce the risk of burns or fire:
    - \* **DO NOT** attempt to open the batteries.
    - \* **DO NOT** crush, puncture, short contacts or dispose of in fire or water.
    - \* **DO NOT** expose to temperatures above 60°C (140°).
- Replace only with the batteries designed for this product.  
 Recycle or dispose of used batteries as stipulated by local regulation.  
 If the electrolyte in the batteries gets on your skin, thoroughly wash with soap and water. If it gets in your eyes, rinse thoroughly with cool water and seek immediate medical attention.

## 2. INTRODUCTION

**LED181:** Composite case lantern with hanging handle. Operates 4 SMD LEDs that feature two selectable light settings producing up to 200 lumens of warm white light. Requires 3 x AA batteries (not included).

**LED182:** Composite case lantern with hanging/carry handle. Operates 10 SMD LEDs that feature three selectable light settings producing up to 400 lumens of warm white light. Requires 3 x D batteries (not included).

## 3. SPECIFICATION

<b>Model No:</b> .....	<b>LED181</b> .....	<b>LED182</b>
Lumen Output: .....	High/Low: - 200/18lm.....	High/Med/Low: - 400/145/18lm
Operating Time: .....	High/Low: - 12/70hr .....	High/Med/Low: - 18/75/800hr
LED Qty: .....	4 SMD .....	10 SMD
Battery: .....	3 x AA (not included).....	3 x D (not included)

## 4. OPERATION

### 4.1. Battery fitting/replacement.

#### 4.1.1. LED181:

- 4.1.1.1. Open battery compartment by turning the bottom of the lantern anticlockwise.
- 4.1.1.2. Insert 3 x AA batteries, observing correct polarity.
- 4.1.1.3. Replace battery compartment cover and lock by turning clockwise.

#### 4.1.1.4. LED182:

- 4.1.1.5. Open battery compartment by turning anticlockwise.
- 4.1.1.6. Insert 3 x D batteries, observing correct polarity.
- 4.1.1.7. To replace the battery compartment cover, ensure that the two posts which protrude from the cover locate in the apertures either side of the battery nearest the switch.
- 4.1.1.8. Turn clockwise to lock.

### 4.2. Operation.

#### 4.2.1. LED181:

Press the switch once for high output, twice for low, a third time to switch off.

#### 4.2.2. LED182:

Press the switch successive times for: high, medium, low and off.



#### ENVIRONMENT PROTECTION

Recycle unwanted materials instead of disposing of them as waste. All tools, accessories and packaging should be sorted, taken to a recycling centre and disposed of in a manner which is compatible with the environment. When the product becomes completely unserviceable and requires disposal, drain any fluids (if applicable) into approved containers and dispose of the product and fluids according to local regulations.



#### WEEE REGULATIONS

Dispose of this product at the end of its working life in compliance with the EU Directive on Waste Electrical and Electronic Equipment (WEEE). When the product is no longer required, it must be disposed of in an environmentally protective way. Contact your local solid waste authority for recycling information.



#### BATTERY REMOVAL (FOR DETAILS SEE SECTION 4.1.)

Under the Waste Batteries and Accumulators Regulations 2009, Jack Sealey Ltd are required to inform potential purchasers of products containing batteries (as defined within these regulations), that they are registered with Valpak's registered compliance scheme. Jack Sealey Ltd Batteries Producer Registration Number (BPRN) is BPRN00705.

**Note:** It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice.

**Important:** No Liability is accepted for incorrect use of this product.

**Warranty:** Guarantee is 12 months from purchase date, proof of which is required for any claim.

Sealey Group, Kempson Way, Suffolk Business Park, Bury St Edmunds, Suffolk. IP32 7AR



01284 757500



01284 703534



sales@sealey.co.uk



www.sealey.co.uk