



RCD SAFETY ADAPTOR 230V

MODEL NO: **RCD981**

Thank you for purchasing a Sealey product. Manufactured to a high standard, this product will, if used according to these instructions, and properly maintained, give you years of trouble free performance.

IMPORTANT: PLEASE READ THESE INSTRUCTIONS CAREFULLY. NOTE THE SAFE OPERATIONAL REQUIREMENTS, WARNINGS & CAUTIONS. USE THE PRODUCT CORRECTLY AND WITH CARE FOR THE PURPOSE FOR WHICH IT IS INTENDED. FAILURE TO DO SO MAY CAUSE DAMAGE AND/OR PERSONAL INJURY AND WILL INVALIDATE THE WARRANTY. KEEP THESE INSTRUCTIONS SAFE FOR FUTURE USE.



Refer to instruction manual



Indoor use only

1. SAFETY

- ✓ For use with a 230V AC supply only.
- ✓ Test before each use (see section 4). If the unit trips repeatedly, seek professional advice.
- ✓ **DO NOT** allow to get wet or use in a damp atmosphere.
- ✗ **DO NOT** drop or subject to shock.
- ✗ **DO NOT** use if it suspected that the unit has been damaged.
- WARNING:** This RCD is an electrical safety device and should not be regarded as a substitute for basic electrical safety precautions.

2. INTRODUCTION

Cuts power automatically to protect against electrocution. Suitable for all types of indoor and outdoor electrical appliances. Easy-to-use, two-button operation. No wiring needed - plugs straight into 13A socket. No need to remove from socket to reset unit.

3. SPECIFICATION

Model No:..... **RCD981**
 Supply:.....230V
 Maximum Load:.....3120W
 Maximum Operating Current: 13A
 Trip Speed:..... 30ms
 Trip Current:30mA

4. OPERATION

- 4.1. Insert the RCD adaptor into a fixed 13A socket and then plug the portable appliance into the RCD outlet socket.
- 4.2. **Testing**
 - 4.2.1. Test the RCD before each use.
 - 4.2.2. With the appliance connected, push the 'Test' button. The RCD will automatically cut the electricity supply and the indicator flag will show 'off'
 - 4.2.3. To reconnect the electrical supply, press the 'reset' button. The outlet socket will be energised and the indicator flag will show 'on' (red).
- 4.3. If the RCD disconnects the electrical power at any time, remove the unit from the outlet socket and investigate the apparent fault.
- 4.4. If the RCD continues to trip, consult a competent electrician.



WEEE REGULATIONS

Dispose of this product at the end of its working life in compliance with the EU Directive on Waste Electrical and Electronic Equipment (WEEE). When the product is no longer required, it must be disposed of in an environmentally protective way. Contact your local solid waste authority for recycling information.

Note: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice.

Important: No Liability is accepted for incorrect use of this product.

Warranty: Guarantee is 12 months from purchase date, proof of which is required for any claim.

Sealey Group, Kempson Way, Suffolk Business Park, Bury St Edmunds, Suffolk. IP32 7AR



01284 757500



01284 703534



sales@sealey.co.uk



www.sealey.co.uk



EC DECLARATION OF CONFORMITY

Description and Function: **Hammer Drill/Driver 12V 10mm - Body Only**

Model/Type: **CP1201 v1**

Manufacturing Date/Serial Number where applicable:

2006/42/EC Machinery Directive

2011/65/EU RoHS Directive

This declaration of conformity is issued under the sole responsibility of the manufacturer:

Jack Sealey Ltd, Kempson Way, Suffolk Business Park, Bury St Edmunds, Suffolk. IP32 7AR

Declaration of Conformity in accordance with the above Directive(s).

References to harmonised standard(s)

EN 60745-1:2009+A11

EN 60745-2-1:2010

.....
.....
.....
.....

Technical file compiled by: **Jack Sealey Ltd**

Being the responsible person appointed by the manufacturer.

Signed.....

Date..... 27 February 2018

Name..... Steve Buckle.

Position..... Marketing Director.

Place: Bury St Edmunds

Sealey Group, Kempson Way, Suffolk Business Park, Bury St Edmunds, Suffolk. IP32 7AR
 01284 757500 01284 703534 sales@sealey.co.uk www.sealey.co.uk