



# 1W SMD LED PENLIGHT 9-IN-1 MULTI-TOOL

MODEL NO: LED091

Thank you for purchasing a Sealey product. Manufactured to a high standard, this product will, if used according to these instructions, and properly maintained, give you years of trouble free performance.

**IMPORTANT:** PLEASE READ THESE INSTRUCTIONS CAREFULLY. NOTE THE SAFE OPERATIONAL REQUIREMENTS, WARNINGS & CAUTIONS. USE THE PRODUCT CORRECTLY AND WITH CARE FOR THE PURPOSE FOR WHICH IT IS INTENDED. FAILURE TO DO SO MAY CAUSE DAMAGE AND/OR PERSONAL INJURY AND WILL INVALIDATE THE WARRANTY. KEEP THESE INSTRUCTIONS SAFE FOR FUTURE USE.



Refer to instructions

## 1. SAFETY

- ✓ Inspect the unit for wear and damage to ensure items are safe before use or inserting a battery. If worn or damaged **DO NOT** use.
- ✗ **DO NOT** shine lamp directly into your, another person's or an animal's eyes.
- ✗ **DO NOT** use the lamp if you suspect that the battery or the lamp casing is damaged.
- ✗ **DO NOT** expose to temperatures above 60°C (140°F).

## 2. INTRODUCTION

Produces bright white light from single 1W SMD LED. Sliding action light focus can be adjusted from spotlight to wide area. Strobe light function for emergencies. Multi-tool function includes Phillips screwdriver, slotted screwdriver, bottle opener, whistle, ball pen and safety hammer. Ideal for storing in glove box. Includes 3 x LR44 batteries (supplied).

## 3. SPECIFICATION

Model No.: ..... LED091  
 Batteries: ..... 3 x LR44  
 LED Type: ..... 1W SMD LED  
 Lumen Output: ..... Up to 30 Lumen  
 Operating Time: ..... 2.5hr

## 4. CONTENTS




fig.1

Item	Description
1	Safety Hammer Cap
2	Safety Hammer / Bottle Opener
3	Screw Driver Bit
4	Bit Housing
5	Whistle
6	Pen
7	Removable pen clip
8	On/Off/Mode Switch, Light Focus Slider, Battery Compartment

## 5. OPERATION

- 5.1. BATTERIES**  
 5.1.1. Before first use, unscrew the battery compartment and remove the film layers separating the batteries from the terminal.
- 5.2. LIGHT MODES**  
 5.2.1. Press the On/Off button (fig.1.7) once to turn the LED on. Press once more to start strobe function. Press once more to turn LED off.  
 5.2.2. To adjust focus, slide the lens collar (fig.1.7) either forwards or backwards.
- 5.3. SCREW DRIVER FUNCTION**  
 5.3.1. Unscrew the Bit Housing (fig.1.4) from its mating parts. Swap the Screw Driver Bit (fig.1.3) to use either slot or cross head end.



#### ENVIRONMENT PROTECTION

Recycle unwanted materials instead of disposing of them as waste. All tools, accessories and packaging should be sorted, taken to a recycling centre and disposed of in a manner which is compatible with the environment. When the product becomes completely unserviceable and requires disposal, drain any fluids (if applicable) into approved containers and dispose of the product and fluids according to local regulations.



#### WEEE REGULATIONS

Dispose of this product at the end of its working life in compliance with the EU Directive on Waste Electrical and Electronic Equipment (WEEE). When the product is no longer required, it must be disposed of in an environmentally protective way. Contact your local solid waste authority for recycling information.



#### BATTERY REMOVAL

Under the Waste Batteries and Accumulators Regulations 2009, Jack Sealey Ltd are required to inform potential purchasers of products containing batteries (as defined within these regulations), that they are registered with Valpak's registered compliance scheme. Jack Sealey Ltd Batteries Producer Registration Number (BPRN) is BPRN00705.

**Note:** It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice.

**Important:** No Liability is accepted for incorrect use of this product.

**Warranty:** Guarantee is 12 months from purchase date, proof of which is required for any claim.

Sealey Group, Kempson Way, Suffolk Business Park, Bury St Edmunds, Suffolk. IP32 7AR



01284 757500



01284 703534



sales@sealey.co.uk



www.sealey.co.uk